

1. Remove the gun from the stock
2. Remove the airtube/bottle and the valve bracket(1) and the plastic gasket(2) which is located 10mm inside of the valve bracket(1).
3. Remove the manometer, you will see a 2mm diameter hole just under the manometer hole this will have to be drilled through using a 2mm drill. remember to remove the aluminium chips from the block
4. Change the plastic gasket under the manometer and reattach the manometer screw it until you can feel it touching the plastic gasket and then add a half to one whole turn to the manometer depending how you want the manometer to sit
5. Now insert the regulator as shown below just push it into place, and tightly screw the valve bracket(1) back. Reattach the airtube/bottle and the stock!

